

## Installation Instructions

**NOTE:** The accessory described in this instruction manual is intended for use with ASPEQ/Indeeco convector heaters.



### WARNING



This instruction sheet contains vital information for the proper installation and use of the accessory described herein. Carefully read this manual before installation, operation, or service of the accessory. Failure to follow these instructions could result in fire, electric shock, death, serious personal injury, or property damage. Save these instructions for reference by future users.

#### WARNING: HAZARD OF FIRE OR ELECTRIC SHOCK.

1. Be sure electric power is disconnected at main fuse or circuit breaker distribution panel before installation or servicing.
2. The installation must comply with all Local and National Electrical Codes and utility requirements.
3. Refer to installation instructions provided with the heater when installing this accessory.
4. Check accessory and heater nameplate to verify power requirements match power supply coming to heater and accessory. Make sure total power requirements do not exceed ratings of accessory.

### SAVE THESE INSTRUCTIONS

#### INSTALLATION

**NOTE:** Receptacles mounted in filler sections are provided with lead wires to extend 6 inches into wiring compartment. Receptacles mounted in end caps are provided without lead wires.

1. Mount end cap to heater per instruction sheet supplied with heater. Use four (4) no. 6 hex head screws supplied with end cap.
2. Mount heater to wall per instruction sheet supplied with heater.

#### CAUTION ⚠

HEATER AND RECEPTACLE MUST BE WIRED TO SEPARATE POWER SUPPLIES. USE NO. 14AWG COPPER WIRE, NEC CLASS I CIRCUIT SUITABLE FOR AT LEAST 75°.

3. Wire receptacle to a 120VAC, 60 HZ, 15 Amp supply as shown in Figure 2 below.
4. Mount receptacle to end cap - heater assembly as shown in Figure 3 below. Use no. 8 hardware supplied with end cap.
5. Complete heater installation per instruction sheet supplied with heater.




Figure 1

Use NEC Class 1 wiring system with wire suitable for at least 75°C. For receptacle use #14AWG copper.

**Receptacle and heater must have separate power supplies.**




Figure 2




Figure 3

#### LIMITED WARRANTY

All products manufactured by Indeeco are warranted against defects in workmanship and materials for one year from the date of purchase, except heating elements which are warranted against defects in workmanship and materials for five years from date of purchase. This warranty does not apply to damage from accident, misuse, or alteration; nor where the connected voltage is more than 5% above the nameplate voltage; nor to equipment improperly installed or wired or maintained in violation of the product's installation instructions. This warranty does not apply to refurbished products. All claims for warranty work must be accompanied by proof of the date of purchase.

The customer shall be responsible for all costs incurred in the removal or reinstallation of products, including labor costs, and shipping costs incurred to return products to Indeeco. Within the limitations of this warranty, inoperative units should be returned to Indeeco, and we will repair or replace, at our option, at no charge to you with return freight paid by Indeeco. It is agreed that such repair or replacement is the exclusive remedy available from Indeeco.

THE ABOVE WARRANTIES ARE IN LIEU OF ALL OTHER WARRANTIES EXPRESSED OR IMPLIED, AND ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE WHICH EXCEED THE AFORESAID EXPRESSED WARRANTIES ARE HEREBY DISCLAIMED AND EXCLUDED FROM THIS AGREEMENT. Indeeco SHALL NOT BE LIABLE FOR CONSEQUENTIAL DAMAGES ARISING WITH RESPECT TO THE PRODUCT, WHETHER BASED UPON NEGLIGENCE, TORT, STRICT LIABILITY, OR CONTRACT.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above exclusion or limitation may not apply to you. This warranty gives you specific legal rights, and you may have other rights which vary from state to state.

Contact Indeeco in St Louis, MO, at 314-644-4300. Merchandise returned to the factory must be accompanied by a return authorization and service identification tag, both available from Indeeco. When requesting return authorization, include all catalog numbers shown on the products.

#### HOW TO OBTAIN WARRANTY SERVICE AND WARRANTY PARTS PLUS GENERAL INFORMATION

- |                                |   |
|--------------------------------|---|
| 1. Warranty Service or Parts   | <b>314-644-4300</b>   |
| 2. General Product Information | <b><a href="http://www.indeeco.com">www.indeeco.com</a></b> |

**Note:** When obtaining service always have the following:

1. Model number of the product
2. Date of manufacture
3. Part number or description

